



Stake Installer Instructions

- 1) Find the desired installation area for the stake with the fixture.
- 2) Slide the neck of the fixture with the stake into the slot on the Stake Holder of the tool. The Stake Holder should fit most standard sized stakes.
- 3) Be sure your fixture is level and apply pressure on the foot stomper's pegs to press the fixture firmly into the soil.
- 4) Remove the installation tool from the fixture with stake carefully by sliding it back and away from the fixture neck.

