



Timer Installation Instructions

1 Optional A - Use Timer Switch Module



Open the transformer and install the timer switch module into the outlet. This is a circuit completion apparatus that provides an electrical connection.

2 Optional B - Use EZ Timer



If there is a timer switch module pre-installed in the transformer, remove it before installing the EZ timer.

Open the transformer and install the EZ timer into the outlet.

Set your EZ timer to the desired function for everyday use. The next page will show you in detail the various timer functions.

EZ Timer Setting and Functions

2 Hours: Function that keeps the luminaires on for 2 hours after dusk.

4 Hours: Function that keeps the luminaires on for 4 hours after dusk.

6 Hours: Function that keeps the luminaires on for 6 hours after dusk.

8 Hours: Function that keeps the luminaires on for 8 hours after dusk.

10 Hours: Function that keeps the luminaires on for 10 hours after dusk.

Off: Manual off override function. This turns off all luminaires on the transformer overriding the photocell.

ON: Manual on override function. This turns on all luminaires on the transformer overriding the photocell.

Dusk-Dawn: Function that utilizes the timer's internal photocell, turning the luminaires on at dusk and off again at dawn.

Pilot light: This is a check light to verify that the timer is receiving power and functioning properly. This does have a few second delay.

