

## AMP<sup>®</sup> Lens & Filter Storage Binder

### APPLICATIONS

The AMP<sup>®</sup> Lens & Filter Storage Binder provides a place where the designer can store and transport fixture lenses and filters. Without this binder, lenses and filters may be lost or damaged - especially when they are thrown into boxes that may contain other products.

A second use for the binder is for testing and demonstrations. Taken to the project site at night, the designer can select lenses and filters to test effects or to demonstrate effects to the client.

### INSTRUCTIONS

#### As a Storage Binder

1. Purchase lenses and filters.
2. Insert them into proper binder section pockets.
3. Take care to handle these by the edges only, and avoid scratching them on the open edges of the vinyl pockets.
4. If desired, use rectangle labels (provided) to label (with product name) each pocket or pocket page.
5. If lenses or filters are overly loose in pockets, seal the pocket closed with a round label (provided).
6. Both label types can be easily removed.

#### As a Testing & Demonstration Tool

1. When using filters and lenses, you should always test the effects before committing to purchases.
2. You may also want to demonstrate effects to your client.
3. The binder allows you to bring the various lenses and filters into the field so you can test them at night.
4. Bring a flashlight to help you find the correct lenses in the dark.
5. A white sheet of paper has been inserted between each color filter page so colors may be viewed without removing the filter. Since, dichroic filters appear to be different colors when viewed at different angles, view each filter from directly above the page. You can back-light the white paper to better see the color.
6. Be sure to test them one at a time, removing each from its pocket then returning it to the same pocket before removing another. This prevents placing a lens or filter in a pocket with the wrong label.
7. Take notes to record observed results.

### CONTENTS

The AMP<sup>®</sup> Lens & Filter Storage Binder contains:

- ▶ (1) 3-Ring Binder
- ▶ (1) Sheet of labels for tabs & product names
- ▶ (1) Sheet of circles to seal pockets
- ▶ (3) Tabbed section dividers
- ▶ (6) 12-pocket (2") clear vinyl sheets
- ▶ (9) 6-pocket (3") clear vinyl sheets

### CARE & MAINTENANCE

Please follow these instructions to prevent damage to the binder and its contents:

- 1. Do not store the binder in direct sunlight or in a hot car.**
2. Use the round removable labels (provided) to prevent loose lenses or filters from slipping out of their pockets.
3. Keep the inside of the binder and pocket pages clean by wiping with a damp cloth.

### RE-ORDERING CONTENTS

The binder and its content pieces may be re-ordered. Call customer support for more information.