


# Timer and Photocell Combination


## Installation Instructions

### 1 Install Plugs to Transformer Box



Open the transformer door by releasing the latch on its side. Run the wires from the photocell through the hole on the side of the transformer box. Clamp the photocell wires by using both of the plugs. Insert plugs A and B simultaneously into the hole on the side of the transformer box, then secure it with the lock cap and hand tighten until snug. Connect the plug of the wire into the timer.

### 2 Install Photocell



Place the photocell at your desired location and secure with self-tapping screws.